

Maintenance Schedule

Items	Pre-ride Check ➤ P. 36	Frequency *1								Annual Check	Regular Replace	Refer to page		
		× 1,000 km	1	6	12	18	24	30	36					
		× 1,000 mi	0.6	4	8	12	16	20	24					
Fuel Line				I	I	I	I	I	I	I	I			-
Fuel Level		I												-
Throttle Operation		I		I	I	I	I	I	I	I	I			69
Air Cleaner *2							R				R			46
Crankcase Breather *3				C	C	C	C	C	C	C				70
Spark Plug				I	R	I	R	I	R					52
Valve Clearance				I	I	I	I	I	I					-
Engine Oil		I		R	R	R	R	R	R	R	R		R	54
Engine Oil Strainer Screen						C			C			C		-
Engine Oil Centrifugal Filter						C			C			C		-
Engine Idle Speed				I	I	I	I	I	I	I	I		I	-
Drive Chain		I		Every 500 km (300 mi):						I	L			65

Maintenance Level

-  : Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled. Procedures are provided in an official Honda Shop Manual.
-  : Technical. In the interest of safety, have your motorcycle serviced by your dealer.

Maintenance Legend

- I** : Inspect (clean, adjust, lubricate, or replace, if necessary)
- R** : Replace
- C** : Clean
- L** : Lubricate

Items	Pre-ride Check ➔ P. 36	Frequency *1									Annual Check	Regular Replace	Refer to page
		× 1,000 km	1	6	12	18	24	30	36				
		× 1,000 mi	0.6	4	8	12	16	20	24				
Brake Fluid *4	<input type="checkbox"/>			<input type="checkbox"/>	2 years	57							
Brake Pads Wear (AFP125CRF)	<input type="checkbox"/>			<input type="checkbox"/>		58							
Brake Shoes/Pads Wear (AFP125CSF)	<input type="checkbox"/>			<input type="checkbox"/>		58, 62							
Brake System (AFP125CRF)	<input type="checkbox"/>		<input type="checkbox"/>		57								
Brake System (AFP125CSF)	<input type="checkbox"/>		<input type="checkbox"/>		57								
Brakelight Switch	<input type="checkbox"/>			<input type="checkbox"/>		63							
Headlight Aim	<input type="checkbox"/>			<input type="checkbox"/>		71							
Lights/Horn	<input type="checkbox"/>												-
Clutch System 	<input type="checkbox"/>		<input type="checkbox"/>		-								
Side Stand	<input type="checkbox"/>			<input type="checkbox"/>		64							
Suspension 	<input type="checkbox"/>			<input type="checkbox"/>		-							
Nuts, Bolts, Fasteners 	<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		-
Wheels/Tyres 	<input type="checkbox"/>			<input type="checkbox"/>		43							
Steering Head Bearings 	<input type="checkbox"/>				<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		-

Notes:

- *1 : At higher odometer reading, repeat at the frequency interval established here.
- *2 : Service more frequently when riding in unusually wet or dusty areas.
- *3 : Service more frequently when riding in rain or at full throttle.
- *4 : Replacement requires mechanical skill.